



List of safety-relevant WITEBLAZE products in the hardware and winter area

Article	Article name	Serial number	Int. number	SAP number	CE declaration of conformity	PSA article	Safety instructions and warnings
Diving mask	APO	2501-1003559	1003559	1109466	x	x	Only use the mask for its intended purpose. Check regularly for damage. Do not pull it over your mouth. Never jump into the water with the mask on. Check for correct fit during use. Rinse the mask with clean water use. Do not expose the mask to excessive heat or sunlight.
Diving mask	APO DESIGN	2501-1003609	1003609	1109552	x	x	Only use the mask for its intended purpose. Check regularly for damage. Do not pull it over your mouth. Never jump into the water with the mask on. Check for correct fit during use. Rinse the mask with clean water use. Do not expose the mask to excessive heat or sunlight.
Diving mask	COZUMEL	2501-1003561	1003561	1109461	x	x	Only use the mask for its intended purpose. Check regularly for damage. Do not pull it over your mouth. Never jump into the water with the mask on. Check for correct fit during use. Rinse the mask with clean water use. Do not expose the mask to excessive heat or sunlight.
Diving mask	AMAZONAS	2501-1003562	1003562	1109467	x	x	Only use the mask for its intended purpose. Check regularly for damage. Do not pull it over your mouth. Never jump into the water with the mask on. Check for correct fit during use. Rinse the mask with clean water use. Do not expose the mask to excessive heat or sunlight.
Diving mask	BELIZE	2501-1003564	1003564	1109464	x	x	Only use the mask for its intended purpose. Check regularly for damage. Do not pull it over your mouth. Never jump into the water with the mask on. Check for correct fit during use. Rinse the mask with clean water use. Do not expose the mask to excessive heat or sunlight.
Diving mask	NINGALOO	2501-1003566	1003566	1109458	x	x	Only use the mask for its intended purpose. Check regularly for damage. Do not pull it over your mouth. Never jump into the water with the mask on. Check for correct fit during use. Rinse the mask with clean water use. Do not expose the mask to excessive heat or sunlight.
Diving mask	GREAT BARRIER	2501-1003567	1003567	1109459	x	x	Only use the mask for its intended purpose. Check regularly for damage. Do not pull it over your mouth. Never jump into the water with the mask on. Check for correct fit during use. Rinse the mask with clean water use. Do not expose the mask to excessive heat or sunlight.
Snorkel	BAR	2501-1003560	1003560	1109465	x		The size of the snorkel should be selected according to the user's lung volume. Snorkels marked "EN 1972<150" should used by persons up to 150 cm (4 ft 11 in) tall. Snorkels marked "EN 1972>150" are intended for use by persons 150 cm (4 ft 11 in) or taller. Use only for the intended purpose. for proper fit. If the color markings at the top of the snorkel are lost or faded, replace them. Do not expose the mask to excessive heat or sunlight. When used by children, an adult must supervise them at all times. supervise .
Snorkel	BAR DESIGN	2501-1003610	1003610	1109553	x		The size of the snorkel should be selected according to the user's lung volume. Snorkels marked "EN 1972<150" should used by persons up to 150 cm (4 ft 11 in) tall. Snorkels marked "EN 1972>150" are intended for use by persons 150 cm (4 ft 11 in) or taller. Use only for the intended purpose. for proper fit. If the color markings at the top of the snorkel are lost or faded, replace them. Do not expose the mask to excessive heat or sunlight. When used by children, an adult must supervise them at all times. supervise .
Snorkel	BONAIRE	2501-1003563	1003563	1109463	x		The size of the snorkel should be selected according to the user's lung volume. Snorkels marked "EN 1972<150" should used by persons up to 150 cm (4 ft 11 in) tall. Snorkels marked "EN 1972>150" are intended for use by persons 150 cm (4 ft 11 in) or taller. Use only for the intended purpose. for proper fit. If the color markings at the top of the snorkel are lost or faded, replace them. Do not expose the mask to excessive heat or sunlight. When used by children, an adult must supervise them at all times. supervise .
Snorkel	PALANCAR	2501-1003565	1003565	1109457	x		The size of the snorkel should be selected according to the user's lung volume. Snorkels marked "EN 1972<150" should used by persons up to 150 cm (4 ft 11 in) tall. Snorkels marked "EN 1972>150" are intended for use by persons 150 cm (4 ft 11 in) or taller. Use only for the intended purpose. for proper fit. If the color markings at the top of the snorkel are lost or faded, replace them. Do not expose the mask to excessive heat or sunlight. When used by children, an adult must supervise them at all times. supervise .
Snorkel	RAJA AMPAT	2501-1003568	1003568	1109456	x		The size of the snorkel should be selected according to the user's lung volume. Snorkels marked "EN 1972<150" should used by persons up to 150 cm (4 ft 11 in) tall. Snorkels marked "EN 1972>150" are intended for use by persons 150 cm (4 ft 11 in) or taller. Use only for the intended purpose. for proper fit. If the color markings at the top of the snorkel are lost or faded, replace them. Do not expose the mask to excessive heat or sunlight. When used by children, an adult must supervise them at all times. supervise .
Diving set	TUBBATAHA DESIGN	2501-1003611	1003611	1109554	x	x	Only use the mask for its intended purpose. Check regularly for damage. Do not pull it over your mouth. Never jump into the water with the mask on. Check for correct fit during use. Rinse the mask with clean water use. Do not expose the mask to excessive heat or sunlight.
Diving set	TUBBATAHA	2501-1003577	1003577	1109551	x	x	Only use the mask for its intended purpose. Check regularly for damage. Do not pull it over your mouth. Never into the water with the mask on. Check for correct fit during use. Rinse the mask with clean water after use. Do not expose the mask to excessive heat or sunlight. The size of the snorkel must be selected according to the user's lung volume. Snorkels marked "EN 1972<150" should used by persons up to 150 cm (4 ft 11 in) tall. Snorkels marked "EN 1972>150" are intended for use persons 150 cm (4 ft 11 in) or taller. Use only for the intended purpose. Check for proper fit. If the color markings at the top of the snorkel are lost or faded, replace them. Do not expose the mask to excessive heat or sunlight. When used by children, an adult must supervise them at all times.
Diving set	WAKATOBI	2501-1003578	1003578	1109549	x	x	Only use the mask for its intended purpose. Check regularly for damage. Do not pull it over your mouth. Never into the water with the mask on. Check for correct fit during use. Rinse the mask with clean water after use. Do not expose the mask to excessive heat or sunlight. The size of the snorkel must be selected according to the user's lung volume. Snorkels marked "EN 1972<150" should used by persons up to 150 cm (4 ft 11 in) tall. Snorkels marked "EN 1972>150" are intended for use persons 150 cm (4 ft 11 in) or taller. Use only for the intended purpose. Check for proper fit. If the color markings at the top of the snorkel are lost or faded, replace them. Do not expose the mask to excessive heat or sunlight. When used by children, an adult must supervise them at all times.
Diving set	YUCATAN	2501-1003580	1003580	1109550	x	x	Only use the mask for its intended purpose. Check regularly for damage. Do not pull it over your mouth. Never into the water with the mask on. Check for correct fit during use. Rinse the mask with clean water after use. Do not expose the mask to excessive heat or sunlight. The size of the snorkel must be selected according to the user's lung volume. Snorkels marked "EN 1972<150" should used by persons up to 150 cm (4 ft 11 in) tall. Snorkels marked "EN 1972>150" are intended for use persons 150 cm (4 ft 11 in) or taller. Use only for the intended purpose. Check for proper fit. If the color markings at the top of the snorkel are lost or faded, replace them. Do not expose the mask to excessive heat or sunlight. When used by children, an adult must supervise them at all times.
Fin	FIDSCHI JR.	2501-1003581	1003581	1109460	x		Check the condition of the device before each use, including checking the buckle and buckle straps. Fins use exclusively in water.
Fin	CEBU	2501-1003583	1003583	1109462	x		Check the condition of the device before each use, including checking the buckle and buckle straps. Fins use exclusively in water.
Swimming goggles	JAMAICA	2501-1003785	1003785	1123083	x	x	Only use swimming goggles for their intended purpose. Check regularly for damage. Do not pull them over your mouth. Never jump into the water with swimming goggles on. Check for correct fit when using. Rinse swimming goggles with clear water use. Do not expose the mask to excessive heat or sunlight.
Swimming goggles	BARBADOS	2501-1003786	1003786	1123080/1123085	x	x	Only use swimming goggles for their intended purpose. Check regularly for damage. Do not pull them over your mouth. Never jump into the water with swimming goggles on. Check for correct fit when using. Rinse swimming goggles with clear water use. Do not expose the mask to excessive heat or sunlight.
Swimming goggles	BAHAMAS	2501-1003787	1003787	1123084/1123086	x	x	Only use swimming goggles for their intended purpose. Check regularly for damage. Do not pull them over your mouth. Never jump into the water with swimming goggles on. Check for correct fit when using. Rinse swimming goggles with clear water use. Do not expose the mask to excessive heat or sunlight.
Swimming belt	SWIM BELT		1003822	1127214			his product is not a toy and must not used for playing or as a substitute for swimming aids. It is intended exclusively to support aqua jogging or similar water exercises. Children may only use the swimming belt under the direct supervision of an adult. Please that the swimming belt does not offer any protection against drowning. People who swim safely should additional swimming aids. Before each use, the product must be for possible damage or wear. Damaged parts must not used under any circumstances. To ensure safety, the buoyancy belt should only ever be used for its intended purpose and all safety instructions should be followed.

Article	Article name	Serial number	Int. number	SAP number	CE Declaration of Conformity	PSA article	Safety instructions and warnings
Inline skate	XOOM 2 BOY		1003450	11082325	x		Always wear suitable protective equipment and only use the skates on flat, dry surfaces. Do not ride in traffic or on unsecured paths. Check the strength of the fasteners, wheels and brakes before each use. Do not expose the skates to high humidity or extreme temperatures to avoid material wear. Not suitable for children under 3 years of age - small parts can pose a choking hazard. Do not continue to use the skates if there is visible damage or functional impairment.
Inline skate	XOOM 2 GIRL		1003451	1108234	x		Always wear suitable protective equipment and only use the skates on flat, dry surfaces. Do not ride in traffic or on unsecured paths. Check the strength of the fasteners, wheels and brakes before each use. Do not expose the skates to high humidity or extreme temperatures to avoid material wear. Not suitable for children under 3 years of age - small parts can pose a choking hazard. Do not continue to use the skates if there is visible damage or functional impairment.
Inline skate	SONIC ALU 84		1003453	1108237	x		Always wear suitable protective equipment and only use the skates on flat, dry surfaces. Do not ride in traffic or on unsecured paths. Check the strength of the fasteners, wheels and brakes before each use. Do not expose the skates to high humidity or extreme temperatures to avoid material wear. Not suitable for children under 3 years of age - small parts can pose a choking hazard. Do not continue to use the skates if there is visible damage or functional impairment.
Inline skate	SONIC W ALU 84		1003455	1108236	x		Always wear suitable protective equipment and only use the skates on flat, dry surfaces. Do not ride in traffic or on unsecured paths. Check the strength of the fasteners, wheels and brakes before each use. Do not expose the skates to high humidity or extreme temperatures to avoid material wear. Not suitable for children under 3 years of age - small parts can pose a choking hazard. Do not continue to use the skates if there is visible damage or functional impairment.
Skateboard	CRAZY KIDS	2501-1003844	1003844	1138672	x		This skateboard is designed for recreational and sports use on paved, flat surfaces. Always wear suitable protective equipment and do not ride in traffic or on unsecured paths. Check the trucks, wheels and deck for damage or loose parts before each use. Do not expose the skateboard to high humidity or extreme temperatures to avoid material wear. Not suitable for children under 3 years of age - small parts can pose a choking hazard. In the event of visible damage or functional limitations, do not
Skateboard	BLOSSOM	2501-1003843	1003843	1138671	x		This skateboard is designed for recreational and sports use on paved, flat surfaces. Always wear suitable protective equipment and do not ride in traffic or on unsecured paths. Check the trucks, wheels and deck for damage or loose parts before each use. Do not expose the skateboard to high humidity or extreme temperatures to avoid material wear. Not suitable for children under 3 years of age - small parts can pose a choking hazard. In the event of visible damage or functional limitations, do not
Skateboard	TWO PIECE	2501-1003845	1003845	1138673	x		This skateboard is designed for recreational and sports use on paved, flat surfaces. Always wear suitable protective equipment and do not ride in traffic or on unsecured paths. Check the trucks, wheels and deck for damage or loose parts before each use. Do not expose the skateboard to high humidity or extreme temperatures to avoid material wear. Not suitable for children under 3 years of age - small parts can pose a choking hazard. In the event of visible damage or functional limitations, do not
Longboard	RASTA	2501-1003363	1003363	1109436	x		This longboard is designed for recreational and sports use on paved, flat surfaces. Always wear suitable protective equipment and do not ride in traffic or on unsecured paths. Check the trucks, wheels and deck for damage or loose parts before each use. Do not expose the skateboard to high humidity or extreme temperatures to avoid material wear. Not suitable for children under 3 years of age - small parts can pose a choking hazard. In the event of visible damage or functional limitations, do not
Protector set	BASIC JR.	2501-1003441	1003441	1108219	x	x	These types of protective kits protect you against any wounds, superficial damage and minor collisions that do not damage any body parts or irreversible injuries. Don't forget to wear protective kits when you go skating and skate carefully. Even the best protection sets cannot protect you completely. The protection sets in this package are suitable for use in physical fitness, leisure or speed skating (normal roller sports). Size JS/JM/S/XS: Class A (users with a body weight of up to 25 kg) Size JL/M: Class B (users with a body weight between 25kg and 50kg) Size L: Class C (users with a body weight over 50kg) These protection sets are suitable for users of skateboards, roller skates and inline skates. These protection sets do not protect against serious damage in the event of a fall at a speed of 13 km/h or faster, but only offer partial protection in the event of a collision with non-moving hard surfaces. These protection sets do not protect you in the event of a collision with moving vehicles. These protection sets are not suitable for use while cycling or motorcycling or for acrobatic skating, rollerblading, inline skating or skating, rollerblading, inline skating at high speeds.
Protector set	COMP JR. 2.0	2501-1003966	1003966	1108218	x	x	These types of protective kits protect you against any wounds, superficial damage and minor collisions that do not damage any body parts or irreversible injuries. Don't forget to wear protective kits when you go skating and skate carefully. Even the best protection sets cannot protect you completely. The protection sets in this package are suitable for use in physical fitness, leisure or speed skating (normal roller sports). Size JS/JM/S/XS: Class A (users with a body weight of up to 25 kg) Size JL/M: Class B (users with a body weight between 25kg and 50kg) Size L: Class C (users with a body weight over 50kg) These protection sets are suitable for users of skateboards, roller skates and inline skates. These protection sets do not protect against serious damage in the event of a fall at a speed of 13 km/h or faster, but only offer partial protection in the event of a collision with non-moving hard surfaces. These protection sets do not protect you in the event of a collision with moving vehicles. These protection sets are not suitable for use while cycling or motorcycling or for acrobatic skating, rollerblading, inline skating or skating, rollerblading, inline skating at high speeds.
Protector set	BASIC ADULT	2501-1003442	1003442	1108222	x	x	These types of protective kits protect you against any wounds, superficial damage and minor collisions that do not damage any body parts or irreversible injuries. Don't forget to wear protective kits when you go skating and skate carefully. Even the best protection sets cannot protect you completely. The protection sets in this package are suitable for use in physical fitness, leisure or speed skating (normal roller sports). Size JS/JM/S/XS: Class A (users with a body weight of up to 25 kg) Size JL/M: Class B (users with a body weight between 25kg and 50kg) Size L: Class C (users with a body weight over 50kg) These protection sets are suitable for users of skateboards, roller skates and inline skates. These protection sets do not protect against serious damage in the event of a fall at a speed of 13 km/h or faster, but only offer partial protection in the event of a collision with non-moving hard surfaces. These protection sets do not protect you in the event of a collision with moving vehicles. These protection sets are not suitable for use while cycling or motorcycling or for acrobatic skating, rollerblading, inline skating or skating, rollerblading, inline skating at high speeds.
Protector set	ADVANCED ADULT 2	2501-1003444	1003444	1108220	x	x	These types of protective kits protect you against any wounds, superficial damage and minor collisions that do not damage any body parts or irreversible injuries. Don't forget to wear protective kits when you go skating and skate carefully. Even the best protection sets cannot protect you completely. The protection sets in this package are suitable for use in physical fitness, leisure or speed skating (normal roller sports). Size JS/JM/S/XS: Class A (users with a body weight of up to 25 kg) Size JL/M: Class B (users with a body weight between 25kg and 50kg) Size L: Class C (users with a body weight over 50kg) These protection sets are suitable for users of skateboards, roller skates and inline skates. These protection sets do not protect against serious damage in the event of a fall at a speed of 13 km/h or faster, but only offer partial protection in the event of a collision with non-moving hard surfaces. These protection sets do not protect you in the event of a collision with moving vehicles. These protection sets are not suitable for use while cycling or motorcycling or for acrobatic skating, rollerblading, inline skating or skating, rollerblading, inline skating at high speeds.
Ski goggles	BLAZY		1003722	1119773, 1119775, 1119778	x	x	Our ski and snowboard goggles comply with the European standard EN174 (from November 2024 EN ISO 18527-1), all goggles comply with Regulation 2016/425 of April 21, 2018 and 89/696/EEC and therefore bear the CE mark. We recommend replacing the glasses after 2 years (or 40 days of use). Even if is no visible damage. Never use the glasses for longer than 5 years from the date of manufacture. Do not these glasses in traffic or to look directly into the sun. Do not use chemical cleaning agents, only water. The instructions must be kept. These ski goggles were developed to protect against reflections, wind and snow. Do not use to protect against hard and sharp objects. Not suitable for children under 3 years of age - small parts can pose a choking hazard.
Ski goggles	ECHO		1003723	1119777	x	x	Our ski and snowboard goggles comply with the European standard EN174 (from November 2024 EN ISO 18527-1), all goggles comply with Regulation 2016/425 of April 21, 2018 and 89/696/EEC and therefore bear the CE mark. We recommend replacing the glasses after 2 years (or 40 days of use). Even if is no visible damage. Never use the glasses for longer than 5 years from the date of manufacture. Do not these glasses in traffic or to look directly into the sun. Do not use chemical cleaning agents, only water. The instructions must be kept. These ski goggles were developed to protect against reflections, wind and snow. Do not use to protect against hard and sharp objects. Not suitable for children under 3 years of age - small parts can pose a choking hazard.

Article	Article name	Serial number	Int. number	SAP number	CE declaration of conformity	PSA article	Safety instructions and warnings
Ski goggles	FLOW		1003725	1119768, 1119766	x	x	Our ski and snowboard goggles comply with the European standard EN174 (from November 2024 EN ISO 18527-1), all goggles comply with Regulation 2016/425 of April 21, 2018 and 89/696/EEC and therefore bear the CE mark. We recommend replacing the glasses after 2 years (or 40 days of use). Even if is no visible damage. Never use the glasses for longer than 5 years from the date of manufacture. Do not these glasses in traffic or to look directly into the sun. Do not use chemical cleaning agents, only water. The instructions must be kept. These ski goggles were developed to protect against reflections, wind and snow. Do not use to protect against hard and sharp objects. Not suitable for children under 3 years of age - small parts can pose a choking hazard.
Ski goggles	FLOW ADVANCED		1003726	1119769, 1119771	x	x	Our ski and snowboard goggles comply with the European standard EN174 (from November 2024 EN ISO 18527-1), all goggles comply with Regulation 2016/425 of April 21, 2018 and 89/696/EEC and therefore bear the CE mark. We recommend replacing the glasses after 2 years (or 40 days of use). Even if is no visible damage. Never use the glasses for longer than 5 years from the date of manufacture. Do not these glasses in traffic or to look directly into the sun. Do not use chemical cleaning agents, only water. The instructions must be kept. These ski goggles were developed to protect against reflections, wind and snow. Do not use to protect against hard and sharp objects. Not suitable for children under 3 years of age - small parts can pose a choking hazard.
Ski goggles	RYDER JR.		1003727	1119757, 1119763	x	x	Our ski and snowboard goggles comply with the European standard EN174 (from November 2024 EN ISO 18527-1), all goggles comply with Regulation 2016/425 of April 21, 2018 and 89/696/EEC and therefore bear the CE mark. We recommend replacing the glasses after 2 years (or 40 days of use). Even if is no visible damage. Never use the glasses for longer than 5 years from the date of manufacture. Do not these glasses in traffic or to look directly into the sun. Do not use chemical cleaning agents, only water. The instructions must be kept. These ski goggles were developed to protect against reflections, wind and snow. Do not use to protect against hard and sharp objects. Not suitable for children under 3 years of age - small parts can pose a choking hazard.
Ski goggles	HORIZON		1003729	1119767, 1119765	x	x	Our ski and snowboard goggles comply with the European standard EN174 (from November 2024 EN ISO 18527-1), all goggles comply with Regulation 2016/425 of April 21, 2018 and 89/696/EEC and therefore bear the CE mark. We recommend replacing the glasses after 2 years (or 40 days of use). Even if is no visible damage. Never use the glasses for longer than 5 years from the date of manufacture. Do not these glasses in traffic or to look directly into the sun. Do not use chemical cleaning agents, only water. The instructions must be kept. These ski goggles were developed to protect against reflections, wind and snow. Do not use to protect against hard and sharp objects. Not suitable for children under 3 years of age - small parts can pose a choking hazard.
Ski goggles	VISION		1003730	1119755, 1119758	x	x	Our ski and snowboard goggles comply with the European standard EN174 (from November 2024 EN ISO 18527-1), all goggles comply with Regulation 2016/425 of April 21, 2018 and 89/696/EEC and therefore bear the CE mark. We recommend replacing the glasses after 2 years (or 40 days of use). Even if is no visible damage. Never use the glasses for longer than 5 years from the date of manufacture. Do not these glasses in traffic or to look directly into the sun. Do not use chemical cleaning agents, only water. The instructions must be kept. These ski goggles were developed to protect against reflections, wind and snow. Do not use to protect against hard and sharp objects. Not suitable for children under 3 years of age - small parts can pose a choking hazard.
Ski goggles	VISTA		1003731	1119754, 1119753, 1119756	x	x	Our ski and snowboard goggles comply with the European standard EN174 (from November 2024 EN ISO 18527-1), all goggles comply with Regulation 2016/425 of April 21, 2018 and 89/696/EEC and therefore bear the CE mark. We recommend replacing the glasses after 2 years (or 40 days of use). Even if is no visible damage. Never use the glasses for longer than 5 years from the date of manufacture. Do not these glasses in traffic or to look directly into the sun. Do not use chemical cleaning agents, only water. The instructions must be kept. These ski goggles were developed to protect against reflections, wind and snow. Do not use to protect against hard and sharp objects. Not suitable for children under 3 years of age - small parts can pose a choking hazard.
Ski goggles	PROSPECT		1003732	1119764, 1119761	x	x	Our ski and snowboard goggles comply with the European standard EN174 (from November 2024 EN ISO 18527-1), all goggles comply with Regulation 2016/425 of April 21, 2018 and 89/696/EEC and therefore bear the CE mark. We recommend replacing the glasses after 2 years (or 40 days of use). Even if is no visible damage. Never use the glasses for longer than 5 years from the date of manufacture. Do not these glasses in traffic or to look directly into the sun. Do not use chemical cleaning agents, only water. The instructions must be kept. These ski goggles were developed to protect against reflections, wind and snow. Do not use to protect against hard and sharp objects. Not suitable for children under 3 years of age - small parts can pose a choking hazard.
Ski goggles	PROSPECT HD		1003733	1119762	x	x	Our ski and snowboard goggles comply with the European standard EN174 (from November 2024 EN ISO 18527-1), all goggles comply with Regulation 2016/425 of April 21, 2018 and 89/696/EEC and therefore bear the CE mark. We recommend replacing the glasses after 2 years (or 40 days of use). Even if is no visible damage. Never use the glasses for longer than 5 years from the date of manufacture. Do not these glasses in traffic or to look directly into the sun. Do not use chemical cleaning agents, only water. The instructions must be kept. These ski goggles were developed to protect against reflections, wind and snow. Do not use to protect against hard and sharp objects. Not suitable for children under 3 years of age - small parts can pose a choking hazard.
Ski helmet	VISOR PRO		1003763	1119785, 1119787, 1119786	x	x	Our helmet complies with the European Regulation (EU) 2016/425 (PPE) and safety test EN 1077. Testing of a tight fit for protection, suitable exclusively for skiing and snowboarding. Not suitable for other sports. The strap must be closed. Also check for children with you. Do not paint or stick anything on the helmet. Do not make any changes to the helmet shell. The protection provided by the helmet may be limited after a fall or impact. Even if no external damage is visible. Then change the helmet and never use a helmet after an accident. Do not take any unnecessary risks. All components of a helmet are subject to a certain amount of ageing depending on treatment and maintenance. The maximum service life is 8 years after the production date marked on the helmet. The helmets of our brand must replaced for safety reasons after 3-5 years from the first use, depending on the intensity of use. Keep the instructions.
Ski helmet	VISOR PRO JR.		1003764	1119784, 1119783	x	x	Our helmet complies with the European Regulation (EU) 2016/425 (PPE) and safety test EN 1077. Testing of a tight fit for protection, suitable exclusively for skiing and snowboarding. Not suitable for other sports. The strap must be closed. Also check for children with you. Do not paint or stick anything on the helmet. Do not make any changes to the helmet shell. The protection provided by the helmet may be limited after a fall or impact. Even if no external damage is visible. Then change the helmet and never use a helmet after an accident. Do not take any unnecessary risks. All helmet components are subject to a certain amount of ageing depending on handling and maintenance. The maximum service life is 8 years after the production date marked on the helmet. The helmets of our brand must replaced for safety reasons after 3-5 years from the first use, depending on the intensity of use. Keep the instructions.
Ski helmet	RYDER		1003765	1119788, 1119790, 1119789	x	x	Our helmet complies with the European Regulation (EU) 2016/425 (PPE) and safety test EN 1077. Testing of a tight fit for protection, suitable exclusively for skiing and snowboarding. Not suitable for other sports. The strap must be closed. Also check for children with you. Do not paint or stick anything on the helmet. Do not make any changes to the helmet shell. The protection provided by the helmet may be limited after a fall or impact. Even if no external damage is visible. Then change the helmet and never use a helmet after an accident. Do not take any unnecessary risks. All components of a helmet are subject to a certain amount of ageing depending on handling and maintenance. The maximum service life is 8 years after the production date marked on the helmet. The helmets of our brand must replaced for safety reasons after 3-5 years from the first use, depending on the intensity of use. Keep the instructions.
Ski helmet	RYDER JR.		1003766	1119792, 1119791	x	x	Our helmet complies with the European Regulation (EU) 2016/425 (PPE) and safety test EN 1077. Testing of a tight fit for protection, suitable exclusively for skiing and snowboarding. Not suitable for other sports. The strap must be closed. Also check for children with you. Do not paint or stick anything on the helmet. Do not make any changes to the helmet shell. The protection provided by the helmet may be limited after a fall or impact. Even if no external damage is visible. Then change the helmet and never use a helmet after an accident. Do not take any unnecessary risks. All helmet components are subject to a certain amount of ageing depending on handling and maintenance. The maximum service life is 8 years after the production date marked on the helmet. The helmets of our brand must replaced for safety reasons after 3-5 years from the first use, depending on the intensity of use. Keep the instructions.
Ice skate	DAVOS		1003708	1120453	x		These skates are designed for recreational and sports use on ice surfaces. Always wear suitable protective equipment and ensure a safe skating environment. Only use the skates on suitable, stable ice surfaces and avoid unsecured waters. Check the blades, fasteners and the tight fit of the shoes before each use. Store the skates in a dry place and protect the blades with protectors to prevent corrosion. Not suitable for children under 3 years of age - small parts can pose a choking hazard. In the event of visible damage or Do not continue to use the device with functional restrictions.
Ice skate	I3000		1003710	1120452	x		These skates are designed for recreational and sports use on ice surfaces. Always wear suitable protective equipment and ensure a safe skating environment. Only use the skates on suitable, stable ice surfaces and avoid unsecured waters. Check the blades, fasteners and the tight fit of the shoes before each use. Store the skates in a dry place and protect the blades with protectors to prevent corrosion. Not suitable for children under 3 years of age - small parts can pose a choking hazard. In the event of visible damage or Do not continue to use the device with functional restrictions.
Ice skate	FIONA		1003709	1120451	x		These skates are designed for recreational and sports use on ice surfaces. Always wear suitable protective equipment and ensure a safe skating environment. Only use the skates on suitable, stable ice surfaces and avoid unsecured waters. Check the blades, fasteners and the tight fit of the shoes before each use. Store the skates in a dry place and protect the blades with protectors to prevent corrosion. Not suitable for children under 3 years of age - small parts can pose a choking hazard. In the event of visible damage or Do not continue to use the device with functional restrictions.

Article	Article name	Serial number	Int. number	SAP number	CE declaration of conformity	PSA article	Safety instructions and warnings
Ice skate	I300 BOY		1003711	1120454	x		These skates are designed for recreational and sports use on ice surfaces. Always wear suitable protective equipment and ensure a safe skating environment. Only use the skates on suitable, stable ice surfaces and avoid unsecured waters. Check the blades, fasteners and the tight fit of the shoes before each use. Store the skates in a dry place and protect the blades with protectors to prevent corrosion. Not suitable for children under 3 years of age - small parts can pose a choking hazard. In the event of visible damage or Do not continue to use the device with functional restrictions.
Ice skate	FIONA GIRL		1003712	1120455	x		These skates are designed for recreational and sports use on ice surfaces. Always wear suitable protective equipment and ensure a safe skating environment. Only use the skates on suitable, stable ice surfaces and avoid unsecured waters. Check the blades, fasteners and the tight fit of the shoes before each use. Store the skates in a dry place and protect the blades with protectors to prevent corrosion. Not suitable for children under 3 years of age - small parts can pose a choking hazard. In the event of visible damage or Do not continue to use the device with functional restrictions.
Drinking bottle	BLAZE		1003449	1139418, 1139419, 1109415, 1139418, 1139419, 1149198, 1149197, 1149199			Do not freeze when the bottle full. Do not boil the bottle or it in the microwave. Do not for carbonated drinks. Do not for non-drinkable liquids. Do not use brushes or abrasive cleaners for scrubbing. Make sure the lid screwed on tightly before use. CAUTION: Small parts can be swallowed. Packaging materials and small parts should always kept out of the reach of small children and animals. There is a risk of suffocation! Always rinse the water bottle and lid with cold water before use. After use, always rinse with warm water and detergent only. Do not use brushes or abrasive cleaners for scrubbing. Allow to air dry completely before storing and always store without the lid. Rinse by hand or in the upper Clean the dishwasher compartment with a wash cycle up to 45 degrees.
Drinking bottle	BLAZE INSU		1003863	1138733, 1138734, 1138732, 1139429, 1149200, 1149201, 1149202			Do not freeze when the bottle full. Do not boil the bottle or it in the microwave. Do not for carbonated drinks. Do not for non-drinkable liquids. Do not use brushes or abrasive cleaners for scrubbing. Make sure the lid screwed on tightly before use. CAUTION: Small parts can be swallowed. Packaging materials and small parts should always kept out of the reach of small children and animals. There is a risk of suffocation! Always rinse the water bottle and lid with cold water before use. After use, always rinse with warm water and detergent only. Do not use brushes or abrasive cleaners for scrubbing. Allow to air dry completely before storing and always store without the lid. Rinse by hand or in the upper Clean the dishwasher compartment with a wash cycle up to 45 degrees.
Drinking bottle	FLASH 750		1003556	1109441			Do not freeze when the bottle full. Do not boil the bottle or it in the microwave. Do not for carbonated drinks. Do not for non-drinkable liquids. Do not use brushes or abrasive cleaners for scrubbing. Make sure the lid screwed on tightly before use. CAUTION: Small parts can be swallowed. Packaging materials and small parts should always kept out of the reach of small children and animals. There is a risk of suffocation! Always rinse the water bottle and lid with cold water before use. After use, always rinse with warm water and detergent only. Do not use brushes or abrasive cleaners for scrubbing. Allow to air dry completely before storing and always store without the lid. Rinse by hand or in the upper Clean the dishwasher compartment with a wash cycle up to 45 degrees.
Drinking bottle	FLASH 750 Promo		1003557	1109443			Do not freeze when the bottle full. Do not boil the bottle or it in the microwave. Do not for carbonated drinks. Do not for non-drinkable liquids. Do not use brushes or abrasive cleaners for scrubbing. Make sure the lid screwed on tightly before use. CAUTION: Small parts can be swallowed. Packaging materials and small parts should always kept out of the reach of small children and animals. There is a risk of suffocation! Always rinse the water bottle and lid with cold water before use. After use, always rinse with warm water and detergent only. Do not use brushes or abrasive cleaners for scrubbing. Allow to air dry completely before storing and always store without the lid. Rinse by hand or in the upper Clean the dishwasher compartment with a wash cycle up to 45 degrees.
Drinking bottle	SOFT RUNNING FLASK		1003862	1139021			Do not freeze when the bottle full. Do not boil the bottle or it in the microwave. Do not for carbonated drinks. Do not for non-drinkable liquids. Do not use brushes or abrasive cleaners for scrubbing. Make sure the lid screwed on tightly before use. CAUTION: Small parts can be swallowed. Packaging materials and small parts should always kept out of the reach of small children and animals. There is a risk of suffocation! Always rinse the water bottle and lid with cold water before use. After use, always rinse with warm water and detergent only. Do not use brushes or abrasive cleaners for scrubbing. Allow to air dry completely before storing and always store without the lid. Rinse by hand or in the upper Clean the dishwasher compartment with a wash cycle up to 45 degrees.
Drinking bottle	JORDAN		1003621	1110581, 1150579, 1150568, 1150570, 1141126, 1141124, 1141123, 1141125, 1150577, 1110575, 1150565, 1150567			Do not freeze when the bottle full. Do not boil the bottle or it in the microwave. Do not for carbonated drinks. Do not for non-drinkable liquids. Do not use brushes or abrasive cleaners for scrubbing. Make sure the lid screwed on tightly before use. CAUTION: Small parts can be swallowed. Packaging materials and small parts should always kept out of the reach of small children and animals. There is a risk of suffocation! Always rinse the water bottle and lid with cold water before use. After use, always rinse with warm water and detergent only. Do not use brushes or abrasive cleaners for scrubbing. Allow to air dry completely before storing and always store without the lid. Rinse by hand or in the upper Clean the dishwasher compartment with a wash cycle up to 45 degrees.
Drinking bottle	Kickboard		1003816	1127221			No protection against drowning, use only under constant supervision, this is not a buoyancy aid, do not place on the kickboard or jump on the kickboard

Manufacturer information for all Witeblaze products

SPORT 2000 International GmbH
 North West Ring Strasse 11
 63533 Mainhausen
 GERMANY
info@witeblaze.com
www.witeblaze.com