

		ENGLISH
		ENO: Safety instructions for using TTTM hammocks: Caution when using the products: Accidents can happen.
	HAMMOCKS	Safety Instructions Ensure load does not exceed weight mentioned on hangtag Secure hammock to stable anchors before use. Inspect ropes and carabiners for wear or damage regularly. Use hammock gently—avoid swinging or jumping. Install at a safe height, Between 65 to 75 cm above the ground. Child safety: Never leave children unattended while using the product. Keep away from sharp objects and avoid overloading. Use outdoors for recreational purposes only. Store away from UV rays when unused. Failure to comply with these guidelines can result in severe injury or death. Setup Instructions 1 Choose two secure points and fix moonstraps or nautical ropes (not included) 2 Attach first hook or carabiner 3 Pull out hammock and fix second hook/carabiner 4 Check if installation is <65cm to <75 cm above ground. 5 Sit down, turn and swing legs inside. Invite someone to join you! 6 Lie diagonally for a comfortable flat lay Disclaimer The manufacturer is not responsible for accidents or injuries resulting from improper use or failure to follow these instructions.
	BUG NET	1. Attach the "<i>Bug net</i>" with the minihooks to suspension system on both sides 2 Attach the hammock to the first side of the suspension system 3 Pull the hammock through the "Bug net" and attach it to the opposite side 3 Get into the hammock and close this zipper 5 Adjust the tension of the ridgeline by pulling on the green string (If it's too tight it will slide through the stopper automatically)
	QUILTS AND BLANKETS	Use the "moonquilt/moonblanket" for its intended purpose, ensuring it's suitable for the temperature and conditions. Don't overload the product with extra weight, as it can cause damage to the seams or insulation. Keep sharp objects (like pens or keys) away from the moonquilt to avoid puncturing the fabric. Store in a cool, dry place when not in use. Avoid compression for long periods, as it can damage insulation. Make sure the dry when you store it Follow the recommended temperature range of the product to ensure warmth and safety. Follow washing instructions to avoid damaging the fabric or insulation. Wash and dry gently. Keep away from open flames or extreme heat sources, as this can damage the fabric or insulation.
	SUSPENSION SYSTEMS	Safety and installation Instructions This product is intended for use as a hanging accessory for hammocks only. Do not exceed the maximum load capacity written on hangtag Keep away from children when not in use to prevent accidental injury. Always inspect the rope/strap for signs of wear, fraying, or damage before use. Replace immediately if any defects are found. Avoid contact with sharp edges or abrasive surfaces. Ensure that the rope/strap is securely fastened to a stable, weight-bearing anchor point (e.g., a healthy tree or sturdy beam). The anchor point must support at least 5 times the intended load. Attach the hammock with a secure knot or carabiner to prevent slipping. Maintain a minimum height of 65 cm above the ground to reduce fall risk. Do not swing excessively or perform stunts while in the hammock. Ensure the hammock is at a safe height to allow easy entry and exit. Do not use the hammock or rope under the influence of alcohol or drugs. Store the rope/strap in a cool, dry place when not in use. Clean the rope/strap with mild soap and water; do not use harsh chemicals. Disclaimer The manufacturer is not responsible for accidents or injuries resulting from improper use or failure to follow these instructions.
	CARABINER (6-10-22kn)	Always check and adhere to the weight limit specified for the carabiner. Overloading can cause failure. Use carabiners only for hanging your hammock (e.g., securing suspension ropes, shelter, or gear). Locking Mechanism: Always ensure the locking mechanism is fully engaged before use. Check that the lock is secure to prevent accidental unlocking. Inspect carabiners regularly for wear, cracks, corrosion, or signs of damage. Replace if any issues are found. Do not cross-load the carabiner. Always load the carabiner along its spine, not sideways, to ensure maximum strength. Avoid sudden jerks or sharp impacts that could damage the carabiner or cause it to malfunction. Never modify or alter your carabiner. Any modifications can compromise safety.
	CARABINER 0.3KN	Always check and adhere to the weight limit specified for the carabiner. Overloading can cause failure. This is to hang your accessories (e.g., keys). It is not a climbing carabiner. Always ensure the locking mechanism is fully engaged before use. Check that the lock is secure to prevent accidental unlocking. Inspect carabiners regularly for wear, cracks, corrosion, or signs of damage. Replace if any issues are found. Avoid sudden jerks or sharp impacts that could damage the carabiner or cause it to malfunction. Never modify or alter your carabiner. Any modifications can compromise safety.